



## Application methods

<b>Spray</b>	Use airless spray
<b>Brush</b>	May be used but care must be taken to achieve the specified dry film thickness.
<b>Roller</b>	May be used. However when using roller application care must be taken to apply sufficient material in order to achieve the specified dry film thickness.

## Application data

<b>Mixing ratio (volume)</b>	Single pack.
<b>Thinner/Cleaner</b>	Jotun Thinner No. 2
<b>Guiding data airless spray</b>	
<b>Pressure at nozzle</b>	15 MPa min (150 kp/cm <sup>2</sup> , 2100 psi.).
<b>Nozzle tip</b>	0.53 - 0.78 mm (0.021 - 0.031").
<b>Spray angle</b>	65 - 80°
<b>Filter</b>	Check to ensure that filters are clean.

## Drying time

Drying times are generally related to air circulation, temperature, film thickness and number of coats, and will be affected correspondingly. The figures given in the table are typical with:

- \* Good ventilation (Outdoor exposure or free circulation of air)
- \* Typical film thickness
- \* One coat on top of inert substrate

<b>Substrate temperature</b>	<b>5°C</b>	<b>10°C</b>	<b>23°C</b>	<b>40°C</b>
<b>Surface dry</b>	1,5 h	1 h	0,5 h	0,5 h
<b>Through dry</b>	24 h	20 h	16 h	12 h
<b>Dry for launching <sup>1</sup></b>	12-24 h	10-22 h	8-20 h	6-18 h
<b>Dry to recoat, minimum <sup>2</sup></b>	12 h	10 h	8 h	6 h

1. The interval indicates the time which normally occurs in a drydocking situation where the drying time depends on the total film thickness of primer/antifouling applied. The drying time will increase with increasing film thickness.
1. The surface should be dry and free from any contamination prior to application of the subsequent coat.

The given data must be considered as guidelines only. The actual drying time/times before recoating may be shorter or longer, depending on film thickness, ventilation, humidity, underlying paint system, requirement for early handling and mechanical strength etc. A complete system can be described on a system sheet, where all parameters and special conditions could be included.

## Recommended type of primer:

Anticorrosive primer system suitable for purpose with Vinyguard Silvergrey 88 as a sealer coat/tie coat.

### **Storage**

The product must be stored in accordance with national regulations. Storage conditions are to keep the containers in a dry, cool, well ventilated space and away from source of heat and ignition. Containers must be kept tightly closed.

---

### **Handling**

Handle with care. Stir well before use.

---

### **Packing size**

20 litre container.

Packing may vary from country to country according to local requirements.

---

## Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not breathe or inhale mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

**For detailed information on the health and safety hazards and precautions for use of this product, we refer to the Material Safety Data Sheet.**

---

### DISCLAIMER

The information in this data sheet is given to the best of our knowledge based on laboratory testing and practical experience. However, as the product can be used under conditions beyond our control, we can only guarantee the quality of the product itself. We also reserve the right to change the given data without notice. Minor product variations may be implemented in order to comply with local requirements.

If there is any inconsistency in the text the English (UK) version will prevail.

Jotun is a World Wide company with factories, sales offices and stocks in more than 50 countries. For your nearest local Jotun address please contact the nearest regional office or visit our website at [www.jotun.com](http://www.jotun.com)

ISSUED 26 NOVEMBER 2010 BY JOTUN  
THIS DATA SHEET SUPERSEDES THOSE PREVIOUSLY ISSUED